

PRODUCT MODEL NUMBER: TL-MC84-W SERIES MoCA[®] Wi-Fi ADAPTER



ABOUT THIS MANUAL

DISCLAIMER

No part of this document may be reproduced in any form without the written permission of the copyright owner.

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. TRANSLITE GLOBAL LLC shall have no liability for any error or damage of any kind resulting from the use of this document.

COPY WARNING

This document includes some confidential information. Its usage is limited to the owners of the product that it is relevant to. It cannot be copied, modified, or translated in another language without prior written authorization from TRANSLITE GLOBAL LLC

INDEX

TABLE OF CONTENTS

CHAPTER 1 PRODUCT INTRODUCTION	03
CHAPTER 2 PACKING LIST	03
CHAPTER 3 GETTING TO KNOW THE DEVICE	04
CHAPTER 4 DEVICE LOGIN	07
CHAPTER 5 EQUIPMENT INSTALLATION	09
➤ CABLE MODEM CONNECTION (INTERNET ONLY)	
➤ CABLE MODEM CONNECTION (INTERNET ONLY + TV)	
➤ ROUTER CONNECTION (INTERNET ONLY)	
➤ ROUTER CONNECTION (INTERNET + TV)	
CHAPTER 6 ACCESSING THE DEVICE GUI	13
CHAPTER 7 TECHNICAL SPECIFICATIONS	36
CHAPTER 8 FAULT DIAGNOSIS	38
CHAPTER 9 HAZARDOUS SUBSTANCE CONTENT TABLE	38
CHAPTER 10 SAFETY PRECAUTIONS	39
CHAPTER 11 SALES & SUPPORT	40

CHAPTER 1

PRODUCT INTRODUCTION

As a home terminal product, TL-MC84-W network adapter uses MoCA® 2.5 technology, with working frequency range of 1125 - 1675MHz. It supports dual-band Wi-Fi, that can enhance broadband gaming, streaming and video on demand services to every room.

CHAPTER 2

PACKING LIST

Before installing this product, please check if the following items are included in the package. In case of any loss or damage in the contents, please contact your supplier.

S.No.	Item Name	Quantity
1	TL-MC84-W Terminal Equipment	1 piece
2	Power Adapter	1 piece
3	User Manual	1 piece
4	Ethernet Cable	1 piece
5	Coaxial Cable	1 piece

CHAPTER 3

GETTING TO KNOW THE DEVICE

3.1 FRONT PANEL




Fig. 3-a

Indicator light	Description	Functions
PWR	Power light	Off: no electricity, or power failure On: normal power supply
MoCA	Coaxial connection indicator light	Off: no connection to terminal equipment On: connected to terminal equipment Blinking: sending and receiving data
2.4G	2.4G Wi-Fi indicator light	Off: 2.4G Wi-Fi closed On: 2.4G Wi-Fi opened Blinking: sending and receiving data
5G	5G Wi-Fi indicator light	Off: 5G Wi-Fi closed On: 5G Wi-Fi opened Blinking: sending and receiving data
GE1、FE2-4	Network connection indicator light	Off: no connection to user equipment On: normally connected to user equipment Blinking: sending and receiving data

3.2 BACK PANEL




Fig. 3-b

Interface	Description
IN-OUT	TV signal input port for connecting optical receiver equipment.
MoCA	Mixed outlet for TV signals and MoCA signals.
GE1	1000Mbps Ethernet interface, RJ45 interface.
FE2/FE3/FE4	100Mbps Ethernet interface, RJ45 interface.
DC 12V	DC 12V/1A power input port.
RESET	Long press reset key for 3s to restore to factory settings.
WPS	Long press the WPS key for 3s-5s to synchronize sub-device settings. Auto join a device/terminal without a password.

3.3 SIDE PANEL




Fig. 3-c

Toggle switch as shown in the picture to OFF position to turn off the power, and to ON position to turn on the power.

3.4 MECHANICAL DESIGN




Fig. 3-d

CHAPTER 4

DEVICE LOGIN



Fig. 3-e

Step 1: Make sure the device is powered on and connected to a PC using an ethernet cable. There are four ETH ports on the device, for management any port can be used.

Step 2: Configure your PC's IP address to 192.168.10.x range. Examples shown below for Windows and Mac:

4.1 FOR WINDOWS:




Fig. 4-a

4.2 FOR MAC:

Status: **Connected**

USB10/100/1000 LAN is currently active and has the IP address 192.168.10.2.

Configure IPv4:

IP Address:

Subnet Mask:

Router:

DNS Server:

Search Domains:

Fig. 4-b

Step 3: Log in to the device using a browser by <http://192.168.10.1> ,

Username: admin

Password: admin

CHAPTER 5

EQUIPMENT INSTALLATION

TL-MC84-W Setup - Cable Modem Connection (Internet Only)




Fig. 5-a

TL-MC84-W Setup - Cable Modem Connection (Internet + TV)





Fig. 5-b

TL-MC84-W Setup - Router Connection (Internet Only)

ROOM 1



ROOM 2




Fig. 5-c

TL-MC84-W Setup - Router Connection (Internet + TV)




Fig. 5-d

CHAPTER 6

ACCESING THE DEVICE GUI

The MoCA Wi-Fi adapter features an onboard graphical user interface (GUI) that includes user-configurable settings. Some of these settings should be accessed by experienced network technicians only.

To configure the network settings of the adapter:

Step 1: Make sure the device is powered on and connected to a PC using an ethernet cable. There are four ETH ports on the device, for management any port can be used.

Step 2: Configure your PC's IP address to 192.168.10.x range.

Step 3: Log in to the device using a browser by <http://192.168.10.1> ,

Username: admin

Password: admin



Fig. 6-a

6.1 Home Page

The adapter's GUI's home page appears, as shown below.



Home Gateway Status Diagram

Welcome to the home gateway.

This page shows the overall status of the gateway, so that you can quickly browse and view the connection of the network.

For quick setup, below are some basic recommended steps:

1. Click WAN Connection --> Coax --> LAN 2.4G or 5G connection, to access corresponding settings.
2. Click on the gateway icon to view the gateway's detailed status and information.
3. The three small icons under the gateway icon enable you to quickly set up passwords, upgrade software and restart operations.
4. Click on my home network icon to quickly view your home network online device(s) and connection status.




Fig. 6-b

6.2 WAN

WAN setting includes network model selection, WAN connection information and WAN connection setting. The settings displayed on the screen is default and preferred setting for the MoCA adapter.

Network model selection includes two options single model and multiple model as shown in Fig. 6-c




Fig. 6-c

6.2.1 Single Model:

In single model selection, only WAN connection can be set.

The connection mode can be set to Bridge mode (Fig 6-d) or Route mode (Fig. 6-e) depending on the application.

Bridge Mode:





Fig. 6-d

6.2.2 Route Mode:


When the route mode is selected, the link method can be set to DHCP, Static or PPPoE mode as show in Fig. 6-e Click on apply once the selection has been made.



The screenshot shows the 'WAN Connection Settings' interface. The 'Conn Name' is 'R_COAX_DHCP'. 'WAN Binding' is set to 'COAX'. 'Conn Mode' is set to 'Route'. 'Link Method' is set to 'DHCP'. There are 'Apply' and 'Back' buttons at the bottom.

Fig. 6-e


6.2.3 Static mode: The IP address, subnet mask, default gateway, preferred DNS and alternative DNS of network connection can be set as shown in Fig. 6-f



The screenshot shows the 'WAN Connection Settings' interface. The 'Connection Name' is 'R_COAX_Static'. 'WAN Binding' is set to 'COAX'. 'Connection Mode' is set to 'Route'. 'Link Method' is set to 'Static'. Below this, there are input fields for 'IP Address', 'Mask', 'Default Gateway', 'Preferred DNS Server', and 'Spare DNS Server'. There are 'Apply' and 'Back' buttons at the bottom.

Fig. 6-f

6.2.4 PPPoE Mode: The username and password of internet connection can be set manually as shown in Fig. 6-g



WAN Connection Settings

Connection Name: R_COAX_PPPoE

WAN Binding: COAX

Connection Mode: Route

Link Method: PPPoE

User Name:

Password:

MTU: 1492


Apply Back

Fig. 6-g

MTU: The maximum transmission unit of network interface.

6.2.5 Multiple Model:

When compared to single service model, service type and binding ports are added in this model as shown in Fig. 6-h. The service type can be set to display the type of service.



TRANSLITE GLOBAL Home Page **WAN** LAN Wi-Fi Topology More Quit

WAN Connection Settings

Conn Name: B_ETH1_I

WAN Binding: ETH1

Conn Mode: Bridge

Service Type: Internet Video

Binding Port: ETH1 ETH2 ETH3 ETH4


TransLite-2.4G TransLite-2.4G_Guest TransLite-5G TransLite-5G_Guest

Apply Back

Fig. 6-h

6.3 LAN:

The connection mode can be set to Static (Fig 6-i) or DHCP (Fig 6-j)




The screenshot shows the LAN Setting interface with the following configuration:

- Connection Mode:** Static
- IP Address:** 192.168.10.1
- Subnet Mask:** 255.255.255.0
- DHCP Server:** Disable
- Start Address of IP Pool:** 192.168.10.2
- End Address of IP Pool:** 192.168.10.199
- Release Time:** one day

Buttons for 'Apply' and 'Hosts' are visible at the bottom of the form.

Fig. 6-i



The screenshot shows the LAN Setting interface with the following configuration:

- Connection Mode:** DHCP
- IP Address:** 192.168.10.1
- Subnet Mask:** 255.255.255.0
- DHCP Server:** Disable
- Start Address of IP Pool:** 192.168.10.2
- End Address of IP Pool:** 192.168.10.199
- Release Time:** one day

Buttons for 'Apply' and 'Hosts' are visible at the bottom of the form.

Fig. 6-j

6.4 Wireless Setting:

On this page, the SSID name as well as type of encryption can be set. One can set the region as well (default is set to America) as shown in Fig. 6-k

Band Steering: Band steering is functionality that automatically steers any individual connecting to a wireless network to the best available and supported frequency band, thereby optimizing performance for the client.

Security types: WPA-PSK, WPA2-PSK, WPA/WPA2-PSK Mixed Mode

WiFi Base Setup

WiFi Enable Enable ▼

Band Steering Disable ▼

2.4G WiFi

SSID TransLite-2.4G ▼

SSID Enable Enable ▼

Security No Encryption ▼

5G WiFi

SSID TransLite-5G ▼

SSID Enable Enable ▼

Security No Encryption ▼

Region

America ▼

Fig. 6-k

6.5 Topology:

This page shows the list of wired and wireless devices connected to the adapter along with basic information such as device name, MAC address as well as IP address assigned to the devices as shown in Fig. 6-l




Fig. 6-l

6.6 More

6.6.1 Run Status

Status Table:

The status table page shows basic information of the system, WAN connection as well the wireless configuration details as shown in Fig. 6-m

- Run Status ^
- ★ Status Table
- Network Settings v
- Wireless Setup v
- MoCA Management v
- NAT Setup v
- System Setup v

Status Table

System

Production Name	TL-MC84-W
Serial Number	TB21532010000229
Software Version	V300R005C01B014_r0
Running Time	Oday 1hour 23min 58sec
LAN Mac	18:fd:cb:b0:19:d7
LAN IP	192.168.10.1

WAN Port

ID	Conn Name	Type	Conn Mode	WAN IP	Link Status
1	B_COAX	IP_Bridged	Bridge	–	No Link

Wireless Configuration


2.4G Wi-Fi			5G Wi-Fi		
2.4G WiFi Open			5G WiFi Open		
SSID Number 1			SSID Number 1		
2.4G Wi-Fi Channel AutoChannel(9)			5G Wi-Fi Channel AutoChannel(52)		
WLAN Portocol IEEE 802.11b/g/n			WLAN Portocol IEEE 802.11a/n/ac		
SSID	Security	Encryption	SSID	Security	Encryption
TransLite-2.4G	NONE	NONE	TransLite-5G	NONE	NONE

Fig. 6-m

6.6.2 Network Settings

6.6.2.1 Static Route:

One can use a manually configured routing entry rather than information from dynamic routing traffic.



Static Route

Note: You can manually set static routes on this page.

Destination IP address

Subnet Mask

Default Gateway

Interface

Metric

Destination IP address	Subnet Mask	Default Gateway	Interface	Metric	Action
------------------------	-------------	-----------------	-----------	--------	--------

Fig. 6-n

6.6.2.2 Synchronize Configure:

If ENABLED, all other devices connected to this local network will obtain and synchronize any changes made to the device parameters such as Wi-Fi, SSID, login credentials, MoCA settings, etc.

(Once enabled, push and hold the WPS button for 5s)

Following which, the secondary device will shut down its DHCP server and delete all the WAN connections.

If DISABLED, every device on the local network will be independent of the other. The parameters such as Wi-Fi SSID, login credentials, MoCA settings, etc are not passed on to other devices connected to it.




Fig. 6-o

6.6.3 Wireless Setup:

The following Figures (Fig. 6-p – Fig. 6-s) will represent wireless setup pages and menu’s along with default parameters set.

6.6.3.1 Advanced Setup:

The Wi-Fi channel and bandwidth of the network can be set here as shown in Fig. 6-p




Fig. 6-p

6.6.3.2 Access Control:

Access control is used to block or allow specific client devices to access your network based on a list of blocked devices (Blacklist) or a list of allowed devices (Whitelist).




Fig. 6-q

6.6.3.3 WPS Setup:

Push button configuration mode: Press WPS button to achieve WPS secure connection.

Note: WPS does not support WEP and TKIP encryption.




Fig. 6-r

6.6.3.4 Fast Roaming Setup:

Fast roaming helps to improve the user’s Wi-Fi experience, correct threshold range from -100dBm to -60dBm as shown in Fig. 6-s




Fig. 6-s

6.6.4 MoCA Management:

This section consists of the MoCA setup page (Fig. 6-t) & MoCA Status page (Fig. 6-u)

6.6.4.1 MoCA Setup:

One can set the coaxial port frequency parameter, along with LOF channel, transmission power and Beacon power on this page. The picture (Fig. 6-t) shows default recommended settings.

If this is the first MoCA adapter in your network, it is recommended to disable the “Network Scan” function and enable the “Preferred NC”.

Coax

You can set the parameters of the coaxial port, and select the appropriate frequency range according to the network planning of the operator. When it is the first MOCA device, we suggest to turn off the network search and turn on the preferred NC to make the network connect quickly.

- Frequency Range: D-Ext(1125~1675)MHz
- LOF Channel: 1150Mhz
- TX Power: 10(2dBm)
- Beacon Power: 10(2dBm)
- Net Scan: Enable
- Preferred NC: Disable
- Network Security: Disable

Apply

Fig. 6-t

6.6.4.2 MoCA Status:

The MoCA status page displays basic information as shown in Fig. 6-u

MoCA Status

MoCA Info

- SOC Version: 1.16.1
- My MoCA Version: 2.5
- Network MoCA Version: 2.5
- Link Status: No Link
- Beacon Channel: 1150MHz
- Node ID: 0
- Network Role: SEARCH

Node Info

Device Id	Device Mac Address	Tx Speed(Mbps)	Rx Speed(Mbps)	Atten(dB)

Fig. 6-u

6.6.5 NAT Setup:

NAT settings include ACL setup (Fig. 6-v & 6-w), DMZ setup (Fig. 6-x & 6-y), NAT service (Fig. 6-z, 6-aa & 6-ab)

6.6.5.1 ACL Setup:

On this page, the firewall can be enabled or disabled. It is recommended to enable the firewall as the firewall can build a solid barrier between the external network and your home network.

Fig. 6-v – Firewall Disabled.

Fig. 6-w – Firewall Enabled.




Fig. 6-v




Fig. 6-w

6.6.5.2 DMZ Setup:

The DMZ host feature as shown in Fig opens all service ports to one local host for bidirectional communication.

Fig. 6-x – DMZ Disabled.

Fig. 6-y – DMZ Enabled.




Fig. 6-x




Fig. 6-y

6.6.5.3 NAT Setup:

Network address translation is the ability of a router to translate a public IP address to a private IP address and vice versa.

NAT Setup

Network Address Translation (NAT) is the ability of a router to translate a public IP address to a private IP address and vice versa.

Port Mapping +

Server Name	IP Address	Protocol	Action

Port Trigger +

Server Name	Protocol	Trigger Port	Open Port	Action

Fig. 6-z

Port Mapping

Server Name max length 22

IP Address

Public Port (1-65535)

Private Port (1-65535)

Protocol

Fig. 6-aa

Port Trigger

Server Name max length 22

Protocol

Trigger Port (1-65535)

Open Port (1-65535)

Fig. 6-ab

6.6.6 System Setup:

This section includes system reboot, system manage, system clock synchronous, upgrade, defaults, backup, log information and set up guide menu options described in the following pages.

6.6.6.1 System reboot:

The system can be set to reboot by clicking on the system reboot icon as shown in Fig. 6-ac




Fig. 6-ac

6.6.6.2 System Manage:

In the page, the device login credentials can be changed as well as the TR069 server connection I any can be altered and used as shown in Fig. 6-ad




Fig. 6-ad

6.6.6.3 NTP Settings

Network Time Protocol synchronizes computer clock times across a network. When NTP is enabled, your device contacts the specified NTP server to synchronize the time.





Fig. 6-ae

6.6.6.4 Upgrade:

This page is used to upgrade the firmware of the TL-MC84-W MoCA adapter. You may either upgrade the adapter immediately or schedule an upgrade using the feature as shown in Fig. 6-af



The screenshot displays the TransLite Global web interface. The top navigation bar includes 'Home Page', 'WAN', 'LAN', 'Wi-Fi', 'Topology', 'More', and 'Quit'. The left sidebar menu is expanded to 'System Setup', which includes options like 'System Reboot', 'System Manage', 'NTP Settings', 'Upgrade', 'Defaults', 'Backup', 'Log Information', and 'Setup Guide'. The main content area is titled 'AutoUpgrade Setup' and contains the following settings:

- AutoUpgrade: Enable
- Reboot Mode: Auto Reboot
- Upgrade Time: 03 : 00 to 05 : 00

A warning message states: "System time is not synchronized, automatic timing update function is temporarily unavailable." Below this message is an 'Apply' button. The current software version is listed as 'V300R005C01B014_r2', with a 'Check Upgrade' button next to it.

The 'Local Upgrade' section below features a text input field for the file path, a 'Select File' button, and an 'Upgrade' button.

Fig. 6-af

6.6.6.5 Defaults:

From this page (Fig. 6-ag), one can reset the adapter to factory defaults.




Fig. 6-ag

6.6.6.6 Backup:

The backup page as showing in Fig. 6-ah is used to backup configuration of the adapter to save or apply to other adapters as needed.





Fig. 6-ah

6.6.6.7 Log Information:

The log information menu is used to store logs of device activity as shown in Fig. 6-ai



The screenshot shows the TRANSLITE GLOBAL web interface. The top navigation bar includes 'Home Page', 'WAN', 'LAN', 'Wi-Fi', 'Topology', 'More', and 'Quit'. The left sidebar menu is expanded to 'System Setup', which includes options like 'System Reboot', 'System Manage', 'NTP Settings', 'Upgrade', 'Defaults', 'Backup', 'Log Information', and 'Setup Guide'. The main content area is titled 'System log Setup' and contains the following configuration options:

- Log Enable: Enable
- Record Level: Debug
- Display Level: Error
- Option: Local Buffer

Below these settings is an 'Apply' button. The section below is titled 'System Log Information' and features a 'Log Sort' dropdown menu set to 'As Time Increases' and a 'Get log' button. At the bottom, there is a table header with the following columns:

ID	Time	Level	Log
----	------	-------	-----

Fig. 6-ai

CHAPTER 7

TECHNICAL SPECIFICATIONS

Basic Information	
Technical Standard	MoCA [®] 2.5 Standard
MoCA[®] Chipset Manufacturer/Model	Maxlinear, MXL3710
Wi-Fi Chipset Manufacturer/Model	MTK, MT7620DA+MT7612E
Communication Mode	
Modulation	OFDM
Sub-carrier Number	512*5 (maximum)
Sub-carrier Bandwidth	195.3125KHz
Sub-carrier Modulation	1024QAM
MAC Layer Protocol	TDMA/TDD
RF Parameter	
MoCA port	5 ~ 1675 MHz
MoCA Frequency	1125 ~ 1675 MHz
IN-OUT port	5 ~ 1002 MHz
Channel RF Bandwidth	100MHz*3, 100MHz*4, 100MHz*5
Typical Transmitting Power	+ 2 dBm
Receiving Sensitivity	-70 dBm
Insertion Loss	< 2 dB
Delay	
Typical	3ms
Maximum	5ms

NMS	
NMS	WEB Graphical User Interface
Wi-Fi Parameter	
Operating Frequency	2.4GHz & 5GHz
Wireless Channel	2.4GHz Channel:1,2,3,4,5,6,7,8,9,10,11,12,13, 5GHz Channel:36,40,44,48,52,56,60,64,100, 104,108,112,116,120,124,128,132,136,140,144,149,153,157,161,165
Protocol	2.4G Channel: 802.11 b/g/n 5G Channel: 802.11 a/n/ac , supports 802.11k/r
Maximum Wireless Rate	2.4G WiFi: 2×2 (802.11n: 300Mbps) 5G WiFi: 2×2 (802.11ac: 866Mbps)
Throughput	2.4G WiFi: 180Mbps 5G WiFi: 350Mbps
Interface	
RF Interface Mode	Connector: F type, Female; Impedance: 75 Ohm
RF Interface	1 MoCA [®] input/output port, 1 RF input/output port (CATV)
Ethernet Interface	1*RJ45,1*10/100/1000 1000BASE-T & 3 *10/100BASE-T ports
Power & Consumption	
Power Supply	DC 12V/1A, External Power Adapter
Power Consumption	< 10W
Security	
Grounding	Grounding resistance: <5Ω
Static-Protection	F head, Contact-Discharge 2KV, Air-Discharge 4KV
Dimension & Weight	
Dimension	152*110*37 mm (L×W×H)
Net Weight	< 300g

CHAPTER 8

FAULT DIAGNOSIS

In the process of using the device, if any abnormality is found, the user can make a simple judgment and deal with it. If the problem cannot be solved, please inform the operator to deal with it in time.

Problem description	Handling method
PWR indicator light is not on	<ol style="list-style-type: none"> 1. Check if the power adapter is plugged in tight enough; 2. Try to replace a power socket.
2.4G Wi-Fi indicator light is not on	<ol style="list-style-type: none"> 1. Check if the 2.4G Wi-Fi SSID is enabled
5G Wi-Fi indicator light is not on	<ol style="list-style-type: none"> 1. Check if the 5G Wi-Fi SSID is enabled
MoCA indicator light is not on	<ol style="list-style-type: none"> 1. Check if the coaxial cable is plugged into the MoCA port. 2. Check if the coaxial cable of the equipment is tight enough. 3. Restart the device (power off and then power on).
GE1 and FE2-4 indicator light is not on	<ol style="list-style-type: none"> 1. Check if the cable is in good condition. 2. Replace the ethernet cable. 3. Restart the device (power off and then power on)

CHAPTER 9

HAZARDOUS SUBSTANCE CONTENT TABLE

Name of parts	Hazardous Substance					
	Pb	Hg	Cd	r6+	PBB	PBDE
Substrate unit	×	○	○	○	○	○
Plastic parts	○	○	○	○	○	○
Metal parts	○	○	○	○	○	○
Packaging materials	○	○	○	○	○	○
Attachment	○	○	○	○	○	○

○: indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirements stipulated in SJ/T11363-2006 standard.

×: indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirements stipulated in SJ/T11363-2006 standard.

CHAPTER 10

SAFETY PRECAUTIONS

For proper and safe use of the equipment, please read all safety precautions carefully before using it.

- Do not attempt to repair the equipment by yourself. All maintenance work should be completed by qualified professional technicians.
- Disconnect the power supply from the power socket before cleaning the equipment. Do not use water, paint thinner, benzene, alcohol and other strong cleaning agents.
- Please exclude high-frequency interference signals.
- Please handle the device gently in the process of installing and moving device.
- Please use the provided power adapter.
- Keep it on a horizontal or vertical surface, away from heat or rain, and ventilated.
- Place equipment in a dust-free and dry environment.
- Connect the ground wire to avoid lightning and static damage to the equipment.
- Do not disassemble the equipment by yourself. Disassembling without permission will void warranty of the product.
- Please do not throw the equipment into the trash can at will. Please discard the equipment at the designated recycle bin.
- Please comply with local laws regarding equipment packaging materials and waste equipment, and support recycling activities.

CHAPTER 11

CONTACT SUPPORT

Firmware Upgrades

For firmware upgrades, you may visit our website www.transliteglobal.com or send an email to support@transliteglobal.com

For Sales

North America:

sales@transliteglobal.com

Asia:

sales@translite.co.in

Rest of the World:

sales@transliteglobal.com

For Support

North America:

support@transliteglobal.com

Asia:

support@translite.co.in

Rest of the World:

support@transliteglobal.com